
100



FIGURE!

DESCRIPTION PROPERTY

FIGNE 3

FIRURE 40.

SEND A COMMAND TO THE HOME AUTOMATION CONTROLLER FROM THE HOME AUTOMATION APPLICATION TO CONTROL AN OPERATION OF A LOAD COUPLED WITH THE HOME AUTOMATION CONTROLLER

410

USE THE HOME AUTOMATION
CONTROLLER TO CONTROL THE
OPERATION OF THE LOAD IN
RESPONSE TO THE COMMAND FROM
THE APPLICATION

420

FIGURE 5

SEND A SIGNAL FROM THE HOME SECURITY CONTROLLER TO THE HOME SECURITY APPLICATION TO INDICATE THAT A SENSOR HAS BEEN TRIGGERED

-510

USE THE HOME SECURITY
APPLICATION TO ACTIVATE AN
ALARM IN RESPONSE TO THE
SIGNAL

5 *a*a




FIGURE 6

